

Sephīa


SM23
Bluetooth Sports
EARPHONES




Index

Box Content	3
General Fetures	5
Product Schematic	7
Charging And Battery	9
How to Wear	11
Turning Power ON/OFF	13
Bluetooth Connection	15
Listening Music	17
Conducting Phone Calls	19
Trouble Shooting	21
Precautions	23
Specifications	25


Opening The Box



Spare Earbuds



USB Cable



User Manual



Slider

Features

Wireless

Sephia SM23 has Bluetooth version 4.1 chip which supports Headset, Handsfree, A2DP and AVRCP protocols. That chip ensures the best possible connection between your earphones and the audio source.

Comfort

Ergonomic design and high quality elastic earhooks, combined with silicon noise isolating earbuds are the keys for a comfortable listening experience, even for long hours.


Sound

Sephia SM23 has neodymium drivers combined with high definition Bluetooth chipset which provides punchy bass frequencies and crisp clear trebles.

Durability

Tangle free flat cable, durable housing and elastic earhooks makes the life span longer than similar items.


Overview





1. Earhook
2. Multi Function Button (MFB - Power Button)
3. Volume / Skip Buttons
4. LED Indicator
5. Built in Microphone
6. Micro USB Charging Port

Charging & Battery

Connect the headphones to a computer or USB AC adapter (sold separately) using the supplied dedicated charging cable to charge the battery.



The charging status can be checked from the status indicator LED on the headphones.

Charging status	Status indicator LED color
Charging	 RED Light
Fully charged	 BLUE Light

- When using the headphones for the first time after purchase or when the remaining power of the rechargeable battery is low, charge the battery.

- The headphones can be used for approximately 6 hours of music playback when fully charged.

- It takes approximately 2 hours to fully charge the rechargeable battery from the state of no remaining battery power.

- The headphones can be used for approximately 1 hour of music playback after charging for approximately 20 minutes.

Note


- When the dedicated charging cable is connected to the headphones, the power of the headphones turns off and the mode becomes charging mode. Before use after charging, disconnect the cable from the headphones and turn on the power.

- When connecting the dedicated charging cable to the charging port, be sure to match the cable connector with the shape of the socket. Forcing the connector into the socket will cause damage.

- The rating of the charging output should be DC 5 V, 2.4 A or less.

- The usable time of the headphones differs depending on the temperature of the environment in which they are used and method of use.

How To Wear The Earphones



These headphones are supplied with different sizes of ear tips for adjusting the fit. Use the combination that best suits your ears in order to find the most comfortable fit.


Wear the headphones as shown above.

1. Insert the ear tip of the "L" of the headphones into the left ear, and the ear tip of the "R" into the right ear.
2. Lift the hook parts of the headphones over the ears and then hook them behind the ears.

Adjusting the length of the headphones cable

Attach the supplied slider to the headphones cable as shown in the figure and then adjust the length of the cable.

Setting the slider to the position in the figure will make it difficult for any vibration sound resulting from the cable moving up and down during jogging to be transmitted to the ears.




- Do not forcefully pull or bundle the cable. The cable may break resulting in the inability to output sound.
- After attaching the slider, check that it does not become detached by vibration.

Turning The Power ON/OFF

Turn on the Bluetooth function of the Bluetooth device that you want to connect to beforehand.

Press and hold the headphones' control button for approximately 3 seconds.




- A beep sound is heard and the status indicator LED lights blue for 3 times.

- The headphones automatically connect via Bluetooth to the Bluetooth device when the device is already paired with the headphones.

Turning the power off

Press and hold the control button for approximately 3 seconds.



- A beep sound is heard and the status indicator LED lights red for one time.

Note

- A small amount of power is consumed even when the power is off.

Bluetooth Connection

Pairing

You need to pair a Bluetooth device with the headphones in advance in order to enjoy listening to wireless music or make phone calls. You can connect to a Bluetooth device any time after it has been paired.

Pairing and Connecting a Bluetooth Device

Check that the headphones are not connected to any Bluetooth device before pairing.

1- Turn on the Bluetooth function of your mobile device.



For details, see the Owner's Manual of the Bluetooth device that you want to connect.

When the headphones power is off, press and hold the control button for approximately 6 seconds.



When the status indicator LED lights flashes red and blue alternately indicating that the headphones are in pairing

1- Select "SM23" from the list of devices displayed on the screen of your Bluetooth device.



- When pairing is complete and a Bluetooth connection is established, the status indicator LED on the headphones flashes blue.

- If the power is on, turn the power off before pairing.

- If you are requested to enter a PIN code (pass key), enter "0000" (four zeros).

Connecting Two Devices

Pair with the first device, and turn off the Bluetooth function on the first device, then pair with the second one.

Turn on the Bluetooth functions on the first device and connect the headset manually.

NOTE:

This function needs headphone support. While two devices connected one Bluetooth earphones, some function of the earphones will be restricted.

Listening Music


First check that the headphones and Bluetooth device are connected via Bluetooth.

Playback operations can be performed from both the Bluetooth device and headphones. Here we will explain the operations using the control buttons on the headphones.

Playback/pause

Press the control button once.


- The status indicator LED flashes blue during playback.



Select track

Next track: Press and hold the volume "+" button for approximately 1 second.

Previous track: Press and hold the volume "-" button for approximately 1 second.



Volume adjustment Increase volume (*): Press the volume "+" button.


Decrease volume (**): Press the volume "-" button.

* When the maximum volume is reached, a beep sounds twice. The volume cannot be increased further.

** When the minimum volume is reached, a beep sounds once. The volume cannot be decreased further.

Conducting phone calls

Calls can be made while you are wearing the headphones. You can hear the caller's voice through the headphones, and your voice is picked up by the built-in microphone in the headphones. The paired Bluetooth compatible mobile phone is controlled using the Multi Function Button.



Making a call

Dial operations are done on the paired mobile phone. Audio playback is paused and the call is connected.

Answering an incoming call

When an incoming call is received, audio playback is paused and the ring tone is heard. Press the call button once to answer the call.

Ending a call

Press the call button once during the call. When a call is ended, playback of the paused track is restarted.

Using the call waiting function

If you receive a call while another call is already in progress, you can place the current call (call A) on hold and switch to the new call (call B).

NOTE

Some of mobile phones may not be compatible with these functions.

Press the call button once during the call.

- This places the current call (call A) on hold and switches to the new call (call B).
- When the new call (call B) ends, the headphones return to the call that is on hold (call A).
- To return to the call that is on hold (call A)

Press and hold the call button for approximately 3 seconds during the call (call B).

- This places the current call (call B) on hold and switches to the call that is on hold (call A).

Ignoring an incoming call

Press and hold the call button for approximately 2 seconds when an incoming call is received.

Switching a call from the headphones to a mobile phone

Switch the current call to the mobile phone. **Press the call button twice.**

Troubleshooting

The Bluetooth function of the headphones does not switch on:

-When the rechargeable battery has no power remaining, connect the headphones to a computer using the supplied dedicated charging cable to charge the battery. When the dedicated charging cable is connected to the headphones, the power of the headphones turns off and the

Cannot pair a Bluetooth device:

- Check that the power of the headphones is switched on.
- Move the Bluetooth device that you want to connect closer to the headphones.

Cannot connect using Bluetooth:

- Check that the power of the headphones is switched on.
- Check that the power of the Bluetooth device is on and the Bluetooth function is enabled.
- Check whether the Bluetooth device is in sleep status.
- Pair the devices again.

Sound is not output from the headphones when connected using Bluetooth:

- Check that the power of the headphones is switched on.
- Check that the power of the Bluetooth device is on and the Bluetooth function is enabled.
- Select A2DP as the Bluetooth connection profile on the transmitting Bluetooth device. For details, see the Owner's Manual of the Bluetooth device.
- Check that audio is being played back on the Bluetooth device.
- Increase the volume. Increase the volume on the Bluetooth device if it is necessary to adjust the volume on the Bluetooth device.
- Pair the devices again.

Cannot hear the caller's voice:

- When listening to audio through the headphones, press the call button to switch to the call.
- Check that the power of the headphones is switched on.
- Check that the power of the Bluetooth device is on and the Bluetooth function is enabled.
- Select HSP or HFP as the Bluetooth connection profile on the transmitting Bluetooth device. For details, see the Owner's Manual of the Bluetooth device.
- Check that the Bluetooth device is set to handle calls through the headphones. For details, see the Owner's Manual of the Bluetooth device.
- Increase the incoming call volume.

Precautions for Use

- Be sure to read the Owner's Manual of the device that you want to connect.
- Check the volume settings when using the headphones on public transport or in public places and make sure you do not disturb people around you.
- These headphones are not guaranteed to work with all combinations of Bluetooth devices/mobile phones.
- These headphones do not support connection with all Bluetooth devices/mobile phones.
- Bluetooth wireless technology can communicate over a distance of approximately 10 m. However, obstructions (people, metallic objects, walls, etc.) and radio wave conditions affect the range in which communication is possible.
- The Bluetooth device that you want to connect must support the same profile as these headphones in order to use the Bluetooth function. For details on profiles that the Bluetooth device is compatible with, see the Bluetooth device Owner's Manual.
- Due to features of Bluetooth wireless technology, playback of audio on the headphones is slightly delayed compared to the voice/audio playback on the transmitting device.

Precautions regarding sweat-resistance performance

- These headphones are a product with a sweat-resistance performance equivalent to IPX4. You can exercise in the rain and touch it with wet hands.
- Please do not connect and charge unit if there is water / moisture at the USB connector. Please wipe it off and wait until dry.
- Do not swim with this product.
- Do not wash this product.
- The sweat resistant performance of the system is based on our measurements under the conditions herein described. Note that malfunctions as a result of water immersion caused by misuse by the customer are not covered by the warranty.